


Explosionszeichnung  
Exploded drawing  
Dessin éclaté  
Dibujo explosivo



## Norinco NC226 & NC228

Pos. Designation

- 1 Barrel
- 2 Guide, recoil spring
- 3 Recoil spring
- 4 Slide
- 5 Front sight
- 6 Rear sight
- 7 Inner pin H.D.
- 8 Outer pin H.D.
- 9 Breechblock
- 10 Extractor
- 11 Firing pin
- 12 Spring, firing pin
- 13 Safety lock
- 14 Spring, safety lock
- 15 Frame
- 16 Take-down lever
- 17 Locking insert
- 18 Slide catch lever
- 19 Spring, slide catch lever
- 20 Trigger
- 21 Pivot, trigger
- 22 Trigger bar
- 23 Spring, trigger bar
- 24 Sear
- 25 Spring, sear
- 26 Shaft, sear
- 27 Spring, pin H.D.
- 28 Safety lever
- 29 Hammer

Pos. Designation

- 30 Hammer strut pin
- 31 Hammer pivot pin
- 32 Ejector
- 33 Strut, hammer
- 34 Main spring
- 35 Spring, pin
- 36 Seat, main spring
- 37 Stop, hammer
- 38 Spring, reset
- 39 Pin
- 40 Decocking lever
- 41 Bearing, decocking lever
- 42 Spring, decocking lever
- 43 Magazine catch
- 44 Support plate
- 45 Spring, magazine catch
- 46 Stop, magazine catch
- 47 Spring, magazine stop
- 48 Right grip plate
- 49 Left grip plate
- 50 Screw
- 51 Magazine tube
- 52 Spring, magazine
- 53 Feeder
- 54 Floorplate, magazine
- 55 Insert, magazine