



- No° 1 Front sight
- No° 2 Front sight base
- No° 3 Front sight slide
- No° 4 Front sight base pin
- No° 5 Stock swivel bow pin
- No° 6 Stock swivel bow
- No° 7 Trigger guard bow
- No° 8 Vernier holder
- No° 9 Vernier holder spring
- No° 10 Vernier
- No° 11 Rear sight leaf
- No° 12 Rear sight leaf spring
- No° 13 Guard ring
- No° 14 Barrel
- No° 15 Rear sight elevator
- No° 16 Barrel pin
- No° 17 Receiver
- No° 18 Left extractor
- No° 19 Push pin
- No° 20 Extractor spring
- No° 21 Firing pin (Schlagbolzen)
- No° 22 Extractor
- No° 23 Bolt
- No° 24 Firing pin spring pusher
- No° 25 Firing pin spring
- No° 26 Return spring pusher-tube
- No° 27 Return spring
- No° 28 Breech
- No° 29 Return spring guide
- No° 30 Screw GB 71-85-M3x8
- No° 31 Axis
- No° 32 Pin
- No° 33 Firing base body
- No° 34 Screw
- No° 35 Steel ball GB 308-77
- No° 36 Safety spring
- No° 37 Wheel
- No° 38 Safety lever
- No° 39 Trigger spring
- No° 40 Pin
- No° 41 Trigger
- No° 42 Disconnecter spring
- No° 43 Steel ball 3 GB 308-77
- No° 44 Disconnecter
- No° 45 Sear
- No° 46 Pin
- No° 47 Sear spring
- No° 48 Washer GB 859-87-5
- No° 49 Screw
- No° 50 Magazine latch spring
- No° 51 Magazine latch
- 52 Stock (vormontiert, inkl. 56-62)
- 53 Pad
- 54 Barrel screw
- 55 Magazine (84215)
- 56 Guard
- 57 Wood screw
- 58 Wood screw GB 100-86-5x18
- 59 Stock swivel bow pin
- 60 Sling strap base
- 61 Butt plate
- 62 Butt plate screw
- 63 Barrel support
- 64 Bolt handle
- 65 Screw

# JW14