



- No. 1
- No. 2
- No. 3 long screw
- No. 4
- No. 5 connector
- No. 6 wooden stock
- No. 7 trigger
- No. 8
- No. 9
- No. 10 trigger guard
- No. 11 hook
- No. 12 left extractor
- No. 13
- No. 14
- No. 15
- No. 16 pin
- No. 17 firing pin spring
- No. 18 firing pin
- No. 19 right extractor pin
- No. 20 right extractor spring
- No. 21 right extractor
- No. 22
- No. 23 safety spring
- No. 24 safety
- No. 25 left sear spring (in Nr. 26 set)
- No. 26 left sear (inkl. Nr. 25 als Set)
- No. 27 left sear pin
- No. 28
- No. 29 receive item no. 154185
- No. 30 ejector screw
- No. 31 ejector
- No. 32 stop
- No. 33 pin
- No. 34
- No. 35
- No. 36
- No. 37 screw
- No. 38 right sear
- No. 39 rear sight pin
- No. 40
- No. 41
- No. 42
- No. 43
- No. 44
- No. 45
- No. 46
- No. 47
- No. 48
- No. 49
- No. 50 chain

# 1897 (YL12-1097)