



- No° 1 Barrel item no. 154241
- No° 2 Front sight
- No° 3 Barrel alignment ring
- No° 4 Magazine detent spring
- No° 5 Magazine cap detent
- No° 6 Receiver
- No° 7 Magazine tube
- No° 8 Magazine tube seat
- No° 9 Ejector
- No°10 Ejector spring
- No°11 Ejector rivet (rear & front)
- No°12 Magazine follower
- No°13 Magazine spring
- No°14 Magazine plug
- No°15 Magazine spring retainer
- No°16 Shell latch, left
- No°17 Shell latch, right
- No°18 Receiver stud
- No°19 Breech bolt
- No°20 Locking block
- No°21 Locking block stud
- No°22 Firing pin retractor spring
- No°23 Firing pin
- No°24 Firing pin retaining pin
- No°25 Extractor spring
- No°26 Extractor plunger
- No°27 Extractor
- No°28 Slide
- No°29 Slide plate
- No°30 Slide rivet
- No°31 Fore-end
- No°32 Fore-end tube
- No°33 Action bar, left
- No°34 Action bar, right
- No°35 Fore-end tube nut
- No°36 Trigger plate
- No°37 Safety switch
- No°38 Safety detent ball
- No°39 Safety detent spring
- No°40 Safety spring retaining pin
- No°41 Rear trigger plate pin bushing
- No°42 Trigger plate pin detent spring, rear
- No°43 Trigger
- No°44 Connector, left
- No°45 Connector, right
- No°46 Connector pin
- No°47 Trigger pin
- No°48 Sear
- No°49 Sear pin
- No°50 Sear spring
- No°51 Hammer spring

QJ12

-102

- No°52 Hammer plunger
- No°53 Hammer
- No°54 Action bar lock spring
- No°55 Action bar lock
- No°56 Action bar lock washer
- No°57 Hammer pin
- No°58 Carrier
- No°59 Carrier dog washer
- No°60 Carrier dog
- No°61 Carrier dog pin
- No°62 Carrier dog follower
- No°63 Carrier dog follower spring
- No°64 Trigger plate pin bushing
- No°65 Trigger plate pin detent spring, front
- No°66 Stock
- No°67 Trigger plate pin, rear
- No°68 Butt plate
- No°69 Butt plate screw
- No°70 Butt plate spacer
- No°71 Trigger plate pin, front
- No°72 Stock bolt
- No°73 Washers
- No°74 Magazine cap
- No°75 Stock bearing plate
- No°76 Stock bolt washer