



NP42

Hong Kong Army

- | | | |
|-----------------------------|--------------------------|--------------------------|
| 1.Frame | 15.Firing pin | 29.Hammer spring seat |
| 2.Barrel | 16.Extractor spring | 30.Sleeve |
| 3.Barrel sleeve | 17.Extractor pin | 31.Sear |
| 4.Recoil spring guide | 18.Extractor | 32.Sear spring |
| 5.Recoil spring | 19.Indication lever | 33.Pull rod |
| 6.Connection seat | 20.Firing lever | 34.Pull rod pin |
| 7.Hang-up lever | 21.Trigger hammer pin | 35.Trigger spring |
| 8.Magazine catch | 22.Safety | 36.Trigger |
| 9.Magazine catch spring | 23.Firing mechanism seat | 37.Magazine body |
| 10.Slide | 24.Single-shot lever | 38.Follower |
| 11.Rear sight | 25.Sear pin | 39.Round follower spring |
| 12.Firing pin safety spring | 26.Hammer | 40.Follower base plate |
| 13.Firing pin safety pin | 27.Hammer spring | 41.Magazine cover |
| 14.Firing pin spring | 15.Firing pin | |